U.S. Crane, Inc.

4646 Park Rd. Fayetteville, Ohio 45118 Phone: (513) 530-5252 Fax: (513) 671-1956

Cranes, Hoists: Parts & Service

What inspections are required for hoists, cranes, slings, and below-the-hook devices?

Hoists and Cranes

- √ DAILY (each shift) visual and operational inspection by the operator.
- √ MONTHLY inspection (minimum) with signed reports by a qualified person.
- √ PERIODIC inspections (minimum once per year) with signed reports by a qualified person.

<u>Slings</u>

- $\sqrt{}$ **EACH LIFT**, before use, by the operator.
- √ EACH DAY, before use, by a competent person designated by the employer.
- √ ANNUALLY by a qualified person.

Below-The-Hook Devices

- $\sqrt{}$ **EACH LIFT**, before use, by the operator.
- $\sqrt{}$ **DAILY** by the operator.
- $\sqrt{}$ **ANNUALLY** by a qualified person.